

TOUCHLESS EXPRESS[™] CLEANING INSTRUCTIONS

TAKE-DOWN & DISASSEMBLY



POWER DOWN

Turn power switch to the "Off" position and unplug unit from the power source.

REMOVE INTERNAL JAR WITH LID

Pull out jar and lid. Internal food holding jar and lid are dishwasher safe.

FLUSH & RINSE PUMP

Place lower end of pump into container of hot water. Pump until all remaining product is expelled and only water flows from discharge tube.



REMOVE LID

Pull locking spring pin(s) out on the back of the lid and pull lid up then slide the lid forward to disengage lid slots from the shroud tabs on front of the unit.





Pulling locking spring pin out to unlock the back of the lid

DISASSEMBLE



~ @

CLEANING

WARNING-

ELECTRICAL SHOCK COULD OCCUR

- · Electrical components of unit could be damaged from water exposure or any liquid.
- · Never immerse lid into water or any liquid.
- · Never use a water jet or pressure sprayer on lid.
- · Ensure unit is "OFF" and unplugged.

Pump 100265

CLEAN

Remove lid and pull out pump. After disassembling pump, clean all parts with soap and hot water.



RINSE fully with clear water.

SANITIZE all parts according to local sanitization requirements. All parts in contact with

food must be sanitized.



AIR DRY all parts fully.

CARE OF STAINLESS STEEL

This unit is constructed with stainless steel - one of the best materials for food serving and storage.

If you notice corrosion beginning on any stainless steel surface, you may need to change the cleansing agent, sanitizing agent, or the cleaning procedures you are using.

- · A mildly abrasive nylon or brass brush may be used to remove any stubborn food or mineral deposits on interior surfaces of unit.
- · Fully rinsing and drying all parts can help prevent corrosion. Elements and minerals in tap water can accumulate on stainless steel parts and create corrosion.
- · Do not use products containing acids, alkalines, chlorine, or salt. These agents can corrode stainless steel.

YES!

Use dishwashing soap and hot water

- External surfaces may be wiped clean with a clean damp cloth.
- · Dry all parts fully with a clean soft cloth.
- · Glass and surface cleaners approved for use in food contact areas may be used.
- · Do not use abrasive, caustic or ammonia based cleansers.
- · Do not use metal scrapers or cleaning pads that could scratch surfaces.
- · Internal food holding jar and lid are dishwasher safe.

IMPORTANT!

Periodically clean sensor window with a microfiber cloth to keep it free of debris in order to function properly.

