


QUICK START GUIDE


Server Cream Servers

Tips and tricks to help you get started with your new Cream Server.


1 Remove unit from box and wash all parts properly before use. See separate pump guide for pump instructions.




2 Pre-freeze ice pack(s) for about 12 hours prior to use. Pre-freeze ColdHold jars upside down for about 8 hours prior to use.




3 Insert one ice pack or HoldCold jar into shroud or base. Keep other ice pack or ColdHold jar in freezer to be ready for future use.



4 If using ice packs, install stainless steel jar into shroud or base after ice pack is installed.




5 Pour product into stainless steel jar or HoldCold jar.




Monitor temperature of product and maintain a temperature of 40°F or below to prevent product from becoming hazardous.

Ice pack can hold to proper temperature for up to 4 hours. ColdHold jars can hold proper temperature for up to 12 hours.

6 Install lid or pump.




7 Assembled units.



WANT TO LEARN MORE?

Visit server-products.com/manual-more for your manual, part breakdown, support videos and more.
spsales@server-products.com | 800.558.8722



MODEL
XXXX
P/N
#####

NSF

SERIES
##X ##X

2 YEAR
WARRANTY

REFERENCE YOUR PART NUMBER (P/N) LOCATED ON THE LID OR BASE.